


InsertaDamper Installation Instructions



1. Connect air tube to green resistor.
2. Insert damper into round duct.
3. Rotate top wing of retainer adjuster back toward you.
4. Continue adjusting until damper can not easily be moved
5. Hand tighten only and do not use screws or tape to fasten in place.